



RS485 SettingTool firmware update using SDN Configuration Tool PC software


1. Launch SDN Configuration Tool PC software
2. Click on “+” to add a device (The RS485 SettingTool cannot be automatically discovered)




3. Power on the RS485 SettingTool and select the “Setting Tool Parameters” menu




4. Scroll down to verify the NodeID of the handheld tool (usually is FFFDFFh)




5. On the PC software, select “Product Type” = SettingTool, enter the NodeID and click “OK”



6. The SettingTool is added to the list of device




7. On the SettingTool, keep scrolling down to reach the “Software Update” menu




8. Press “OK” once to get confirmation message



9. Press “OK” again to enter bootloader mode, the handheld tool will shutdown automatically.



10. On the PC software, click on “Update Firmware” to start the update process.



11. The End